

QSil 211 Transparent Liquid Silicone Elastomer

| Description | Property | Test Method | Value | |
|---|--|--|---|---|
| <p>The product is a transparent and colorless silicone formulation and is ideal for optical applications. The viscosity profile enables excellent flow around components and is excellent for potting complex parts. The chemical composition results in a cured product that is hydrolytically stable as well as reversion resistant. The silicone elastomer provides electrical insulation and physical shock resistance of components and enables environmental protection.</p> <p>Key Features</p> <ul style="list-style-type: none"> • Non-yellowing catalyst system • Heat cure required to obtain full properties and adhesion <p>Application</p> <p>This includes internal adhesion promoters to enable excellent primerless adhesion to most substrates.</p> <p>Use and Cure Information</p> <p>IMPORTANT:</p> <p>In order to achieve optimum performance, the same lot number of the A and B components should be used. Mixed lots may not obtain the performance criteria listed on the TDS or Certificate of Analysis.</p> <p>The 'A' part of the product contains the platinum catalyst; great care should be taken when using automatic dispensing equipment. Please ensure that it is not contaminated by residual hydride containing rubber (Part B) in the dispensing equipment, as curing will result. If in doubt, it is advised to thoroughly purge the equipment with a suitable hydrocarbon solvent or silicone fluid.</p> <p>Mixing</p> <p>Both the 'A' and 'B' parts should be well stirred to ensure the material is uniform. If utilizing machine-dispense, ensure the mixing device has sufficient elements to fully homogenize the components of the formulation.</p> <p>Place the required amount of 'A' and 'B' parts by weight at the mix ratio shown opposite, in a clean plastic or metal container of approximately 3 times their volume, and mix until the color of the mixture is uniform. For best results, we recommend vacuum degassing. Degas by intermittent evacuation, the larger volume of the mixing vessel helps prevent overflow during this operation. In the case of automatic dispensing with static mixing head, the two components should be degassed before processing. Recommended vacuum conditions are 30-50 mbar intermittently over 5-10 minutes.</p> <p>Inhibition of Cure</p> <p>Great care must be taken when handling and mixing all addition cured silicone elastomer systems, ensuring that all the mixing tools (vessels and spatulas) are clean and constructed in materials which do not interfere with the curing mechanism. The cure of the silicone can be inhibited by the presence of compounds of nitrogen, sulfur, phosphorus and arsenic; organotin catalysts and PVC stabilizers; epoxy resin catalysts and even contact with materials containing certain of these substances e.g. molding clays, sulfur vulcanized rubbers, condensation-cure silicone rubbers, onion and garlic.</p> <p>Curing Conditions</p> <p>The data offers a guide to the rate of cure at various temperatures, mixing of the components at temperatures between 15 and 25 °C is recommended to ensure adequate pot life for degassing and handling. The pot life can be extended to several hours by chilling the components before mixing.</p> <p>It is important to check the compatibility in preliminary tests if unknown substrates are used.</p> <p>Some formulations are not designed to cure at room temperature and may not develop full physical properties if cured below the minimum listed temperature. The recommended cure temperatures and times are provided for guidance only. The end user must test in their application and process as the quantity of material, size of part, and method of applying heat will influence time and temperature requirements.</p> <p>Health & Safety</p> <p>Safety Data Sheets available on request.</p> <p>Packaging</p> <p>CHT silicone elastomers are available in a variety packaging including bulk containers. Please contact our sales department for more information.</p> | <p>Uncured Product</p> <p>Color A Color B Gel Time at 25°C/77°F Mix Ratio By Weight Specific Gravity A Specific Gravity B Viscosity A Viscosity B</p> | | <p>Transparent Transparent 25 minutes 1:1 1.0 1.0 27,000 cP 27,000 cP</p> | |
| | | <p>Cured Product</p> <p>30 minutes at 150°C Elongation at Break Hardness Shore A Linear Shrinkage (%) Max Working Temp Min Working Temp Tensile Strength</p> | <p>ISO 37 ASTM D 2240-95 ISO 37</p> | <p>285 % 40 < 0.1 % 204 °C / 399 °F -55 °C / -67 °F 4.62 N/mm2 / 670 psi</p> |
| | | <p>Storage</p> <p>Max Storage Temperature Shelf Life</p> | | <p>38 °C / 100 °F 24 mths</p> |
| | Revision Date | 14 Oct 2021 | | |
| | Revision No | 2 | | |

The content set out in the technical data sheet does not contain information upon which you should rely. It is provided for general information purposes only and does not constitute a product specification. You must obtain professional or specialist advice before taking any action based on the information provided in the technical data sheet.

CHT make reasonable efforts to ensure that information set out in the technical data sheet is complete, accurate, and up-to-date. CHT do not, however, make any representations, warranties or guarantees (whether express or implied) that information set out in the technical data sheet is complete, accurate, or up-to-date or that the product will be suitable for your requirements. You should carry out your own testing to determine the applicability of such information and whether the product will be suitable. CHT reserve the right to modify the technical data sheet at any time. The CHT technical service department is available to offer further information and advice and should it be needed to look at modifying current products or custom formulate a new one to meet your specific requirements. Please contact the technical service department.

CHT Germany GmbH: Postfach 12 80, 72002 Tübingen, Bismarckstraße 102, 72072 Tübingen, Germany
Telephone: 07071/154-0, Fax: 07071/154-290, Email: info@cht.com, Homepage: www.cht.com / www.cht-silicones.com

